



WARNING


- The notebook must be turned off and disconnected from its power source. Failure to disconnect the power from the computer may result in personal injury.
- Remove all loose articles of clothing and jewelry before touching components inside the notebook.
- Some components may contain sharp edges. Use caution.
- Ground yourself by touching the metal ports on the back of the notebook. If you are not properly grounded, you could generate static electricity that may cause a component to fail.
- Make sure your hands are dry before performing this task.

Tools Required: None



HINT: Make sure your notebook is completely turned off by going to the Start -> Turn Off Computer menus prior to getting started.

Disconnect the power cord from the outlet and then from the back of the notebook. Disconnect all devices connected to the back of the notebook (e.g. any external devices, mouse, or monitor if applicable).



Step 1: Plug the power cord into the Adapter as shown. **(1)**

Step 2: Plug the power cord into the A/C wall outlet as shown. **(2)**

Step 3: Plug the power cord into the A/C power port on the back of the notebook as shown. **(3)**